

Installation instructions for Corner Slow Feeder

Simple slow feeding for the stable!

With each corner slow kit you should receive:

1 x slow feeder net—with trigger clip attachment

1 x metal bracket

Additional tools needed to install Corner Slow kit :

- Electric Drill
- Minimum of 8 screws to secure the bracket to the wall 6 screws for the feeder.
- Raw plugs if drilling into masonry



Securing your net to the feeder

- 1) Screw the bracket in the chosen corner of the stable with your electric drill approximately 100cm off the floor.
- 2) Use the cable ties to secure the net to the front of the feeder.
- 3) Thread the bungee (held inside the pipe) into the corner of the feeder, securing with a tight knot. Repeat on the opposite side.
- 4) Your feeder should now be securely attached to the front of your corner feeder.

Now its time to Fix your Feeding station to the wall.

Position your "All in one Feeder" in your chosen stable corner at least 10 cm off the ground. (This will allow seeds to drop out and enable a sweeping brush to fit underneath.) Use a pen to mark the desired position on the stable wall.

Pre-drill holes in the edge of the feeder using your electric drill. We recommend you use at least 3 fixings per side of the feeder to securely fit to the wall.

Use the 6 large washers supplied to help secure the fixing point these will help stop the fixing head pulling through the plastic.

Use your screws/ raw plugs simply drill the screws through your pre-drilled holes securing in place.

Using the slow stable feeder

flip the net over the front of the feeder and fill with hay,

Attach the clip onto the metal bracket and watch it slide to the bottom of the feeder as your horse eats it hay.

Relax! This will hopefully save you time, wasted hay & money

